



Nx/DBU
Plug-On Board
Option Module

User Manual

Part Number
1200174L1



901 Explorer Boulevard
P.O. Box 140000
Huntsville, AL 35814-4000
Phone: (256) 963-8000

© 2000 ADTRAN, Inc.
All rights reserved.
Printed in USA.



Notes provide additional useful information.



Cautions signify information that could prevent service interruption

WARNING

Warnings provide information that could prevent damage to the equipment or endangerment to human life.

Federal Communications Commission Radio Frequency Interference Statement

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio frequencies. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Shielded cables must be used with this unit to ensure compliance with Class A FCC limits.



Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Warranty and Customer Service

ADTRAN will replace or repair this product within five (5) years from the date of shipment if it does not meet its published specifications or fails while in service. For detailed warranty, repair and return information See the ADTRAN Equipment Warranty and Repair and Return Policy Procedure.

Return Material Authorization (RMA) is required prior to returning equipment to ADTRAN.

For Service, RMA requests, or more information, contact ADTRAN Technical Support listed on the inside back page of this manual.

LIMITED PRODUCT WARRANTY

ADTRAN warrants that for five (5) years from the date of shipment to Customer, all products manufactured by ADTRAN will be free from defects in materials and workmanship. ADTRAN also warrants that products will conform to the applicable specifications and drawings for such products, as contained in the Product Manual or in ADTRAN's internal specifications and drawings for such products (which may or may not be reflected in the Product Manual). This warranty only applies if Customer gives ADTRAN written notice of defects during the warranty period. Upon such notice, ADTRAN will, at its option, either repair or replace the defective item. If ADTRAN is unable, in a reasonable time, to repair or replace any equipment to a condition as warranted, Customer is entitled to a full refund of the purchase price upon return of the equipment to ADTRAN. This warranty applies only to the original purchaser and is not transferable without ADTRAN's express written permission. This warranty becomes null and void if Customer modifies or alters the equipment in any way, other than as specifically authorized by ADTRAN.

EXCEPT FOR THE LIMITED WARRANTY DESCRIBED ABOVE, THE FOREGOING CONSTITUTES THE SOLE AND EXCLUSIVE REMEDY OF THE CUSTOMER AND THE EXCLUSIVE LIABILITY OF ADTRAN AND IS IN LIEU OF ANY AND ALL OTHER WARRANTIES (EXPRESSED OR IMPLIED). ADTRAN SPECIFICALLY DISCLAIMS ALL OTHER WARRANTIES, INCLUDING (WITHOUT LIMITATION), ALL WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. SOME STATES DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES, SO THIS EXCLUSION MAY NOT APPLY TO CUSTOMER.

In no event will ADTRAN or its suppliers be liable to Customer for any incidental, special, punitive, exemplary or consequential damages experienced by either Customer or a third party (including, but not limited to, loss of data or information, loss of profits, or loss of use). ADTRAN is not liable for damages for any cause whatsoever (whether based in contract, tort, or otherwise) in excess of the amount paid for the item. Some states do not allow the limitation or exclusion of liability for incidental or consequential damages, so the above limitation or exclusion may not apply to Customer.

Table of Contents

List of Figures	xi
List of Tables	xiii
Chapter 1. Introduction.....	1-1
Nx/DBU V.35 Plug-on Board Overview	1-1
Functional Description	1-2
Features	1-2
Nx Features	1-2
DBU Features	1-2
Features Common to the Nx and the DBU	1-3
Interfaces	1-3
Specifications of the Nx/DBU	1-4
Specifications: Nx56/64 (DCE Interface).....	1-4
Specifications: Nx/DBU (DTE Interface)	1-5
Specifications: Nx56/64 and DBU	1-5
Physical Description	1-6
Chapter 2. Installation.....	2-1
Unpack & Inspect	2-1
ADTRAN Shipments Include	2-1
Customer Provides	2-1
Attaching The Plug-on Board	2-2
Placement of the Plug-on Board	2-2
Wiring	2-3
Power-Up Testing and Initialization	2-7
Chapter 3. Installation.....	3-1
Overview	3-1
Front Panel Indicators/Buttons	3-1
Menu Structure	3-1
Nx/DBU Menus Are All Submenus	3-2

Operation	3-2
PORT Status, Submenu of Status	3-4
Operation.....	3-4
Nx/DBU Status Menu Options.....	3-5
DTE DATA/CLOCK	3-5
DTE STATUS	3-5
DTE PORT RATE	3-5
DBU DATA/CNTRL	3-5
DBU CONTROL	3-6
DBU STATUS	3-6
PORT CONFIG, Submenu of CONFIG	3-7
Operation.....	3-7
Nx56/64 CONFIG Menu Options	3-8
DS0 RATE	3-8
TX CLK CNTRL	3-8
DATA	3-8
CTS	3-9
DCD	3-9
DSR	3-9
0 INHIB	3-9
INBAND MODE	3-9
DBU CONFIG Menu Options.....	3-10
BACKUP MODE	3-10
SINGLE END FAILURE	3-11
BOTH END FAILURE	3-11
BACKUP ON	3-11
NET FAIL	3-11
NET/DATA FAIL	3-11
PATTERN VERIFY	3-12
BACKUP DELAY	3-12
RESTORE DELAY	3-12
RETRY DELAY	3-12
NUM RETRIES	3-12
BACKUP TESTING	3-12
BACKUP TEST	3-13
TEST HOUR	3-13
TEST DAY	3-13
WKEND LOCKOUT	3-13
A) ENABLE HR: (0-23)	3-13
B) DISABLE HR: (0-23)	3-13
C) Trap in DBU	3-13
FACTORY RESTORE, Submenu of UTIL	3-14

Operation	3-14
PORT UTILITY, Submenu of UTIL	3-14
Operation	3-14
RUN SELF-TEST, Submenu of TEST	3-15
PORT TEST, Submenu of TEST	3-16
Operation	3-16
1.1 Nx/DBU Menu Options	3-16
PRT/LOCAL	3-16
REMOTE	3-17
REM V.54 CONT	3-17
OFF	3-17
511 PATT	3-17
ON	3-17
OFF	3-17
511 RESULTS	3-18
DBU LOOPBACK	3-18
DBU TEST	3-18
TESTS OFF	3-18
FORCED BACKUP	3-18
INTERFACE TST	3-18
DBU DATA/CNTRL	3-18
DBU TST RESULT	3-19
Appendix A. System Messages	A-1
Index	Index-1

List of Figures

Figure 1-1. Nx/DBU Plug-on Board.....	1-6
Figure 2-1. Attaching the Plug-on Board	2-2
Figure 2-2. Nx/DBU Plug-On Board Cable Assembly	2-5
Figure 2-3. Nx/DBU Plug-On Board Cable Schematic.....	2-6
Figure 3-1. TSU 100 Main Menu Tree	3-2
Figure 3-2. Nx/DBU Plug-On Board Menu Tree	3-3
Figure 3-3. Port Status Submenu.....	3-4
Figure 3-4. DBU Status Submenu	3-6
Figure 3-5. Port Configuration Submenu	3-7
Figure 3-6. Inband Remote Configuration.....	3-10
Figure 3-7. Port Utility Submenu.....	3-14
Figure 3-8. Port Name and Software Version Display	3-15
Figure 3-9. Port Test Submenu	3-16
Figure 3-10. DBU TST Result Submenu	3-19

List of Tables

Table 2-1. Nx/DBU Pin Connection..... 2-3

Table 2-2. DBU V.35 Winchester Pin Connection..... 2-4

Table 3-1. Normal Mode Operation 3-8

NX/DBU V.35 PLUG-ON BOARD OVERVIEW

The Nx/DBU V.35 plug-on board is available for use with any option module with the following TSU units:

- TSU 100
- TSU 120
- TSU 600
- TSU 610

The Nx/DBU V.35 plug-on board installs on any option module in the option slot of the TSU units and provides an additional synchronous V.35 interface port with dial backup capability. When used in these products, this interface port allows an additional DTE to have access to the T1 service with dial backup capability in the event of a T1 failure.

The Nx/DBU plug-on board has a special Y cable that it uses to break apart the Nx and DBU ports from the single V.35 connector. The longer (2 ft.) side of the Y, with the male connector, provides connection to the DBU. The shorter (1 ft.) side, with the female connector, provides access to the Nx port.

In the remainder of this manual, the board will be called the Nx/DBU plug-on board.

FUNCTIONAL DESCRIPTION

The Nx/DBU plug-on board operates on an option module of the TSU units and is under the control of the TSU. The Nx/DBU plug-on board is configured from the front panel or by an external PC program. The internal menus for their configuration are part of the Nx/DBU plug-on board and are automatically installed when the Nx/DBU is installed in a TSU unit.

Features

Nx Features

The general features of the Nx are listed below:

- Data rates from 56 kbps to 2.048 mbps in 56K or 64K increments
- Includes an elastic store for adsorption of rate variations
- Executes and responds to V.54 looping codes
- Outputs a 50% duty cycle output clock at all rates
- Provides an inband control channel (8 kbps for network management communication)
- Generates and checks 511 test pattern toward network
- 511 pattern generator is capable of injecting errors

DBU Features

The following are general features of the DBU:

- Capable of verifying integrity of dial up network with a test pattern without disrupting T1 data
- Detect no data transitions on the data received from the network, with verify over inband channel
- User definable delay between call retries if backup connection is not successfully established

- User definable verification of dial up network (daily, weekly, or on command) without T1 data disruption
- Backup can be initiated by:
 - Alarm conditions on network (AIS, RAI, or Red Alarm)
 - Absence of data transitions for a user-defined delay
 - Uses 8 kbps channel to check end-to-end connectivity before activating backup
 - Disable backup based on hour of day and weekend
 - Uses pattern to validate backup dial network

Features Common to the Nx and the DBU

The following features are common to the Nx and the DBU:

- Configurable by using a PC program (T-Watch)
- Menu operation for easy configuration
- Performs self-test of option card hardware
- Install multiple Nx/DBU modules in a TSU 600
- Hot swappable

Interfaces

The following interfaces are used with the Nx/DBU:

- Two CCITT V.35 electrical (differential)
- One V.35 Winchester connector

SPECIFICATIONS OF THE NX/DBU

Specifications: Nx56/64 (DCE Interface)

DCE Interface	CCITT V.35 synchronous
Rates	56 kbps to 2.048 mbps in 56K or 64K increments
Clock Options	Internal or internal-invert
Tests	Local loopback (bilateral) Remote loopback (V.54)
Test Pattern	511 with errored seconds display and error inject capability
Data Inversion	Menu selectable
1s Density Protection	Force 1s to network after one second of consecutive zeros from DTE User selectable (On/Off)
CTS, DCD, DSR	Normal or Force On
Connector	Winchester (V.35), female

Specifications: Nx/DBU (DTE Interface)

DTE Interface	CCITT V.35 synchronous
Backup Delay	1 sec, 3 sec, 10 sec, 30 sec, 1 min, 5 min, 10 min
DBU Dialing	DTR dialing
Restore Delay	1 sec, 3 sec, 10 sec, 30 sec, 1 min, 5 min, 10 min, Never
Rates	56 kbps through 2.048 mbps in 56K or 64K increments
Clocking	Routes external DCE clocks to external DTE when active
Connector	Winchester (V.35) female
Test	Loopback to DCE Test dialup network Force dial backup

Specifications: Nx56/64 and DBU

Mechanical	Mechanically compatible with option slot of all TSUs
Environmental	Operating temperature from 0°C to 45°C
Tests	Extensive self-test

PHYSICAL DESCRIPTION

The Nx/DBU plug-on board plugs onto any option module used by the TSU family of products (see Figure 1-1).

The PORT X.2/3 indication is linked to the port numbering philosophy of the TSU product family. The X represents the slot number into which the plug-on board is plugged. The 2/3 indicates which port the plug-on board occupies. The port number will be 2 or 3, depending on the option module used.

The TSU 100 has one option slot; therefore the port designation is 1.2/3.

The TSU 120 has one option slot; therefore the port designation is 1.2/3.

The TSU 600 and the TSU 610 each have six option slots; therefore the port numbers would be port 1.2/3 to port 6.2/3. The numbers appear in the front panel LCD menu display.




Figure 1-1. Nx/DBU Plug-on Board

UNPACK & INSPECT

Carefully inspect the plug-on board for any shipping damage. If damage is suspected, file a claim immediately with the carrier and then contact ADTRAN customer service. If possible, keep the original shipping container for use in shipping the plug-on board back for repair or for verification of damage during shipment.

ADTRAN Shipments Include

- The Nx/DBU Plug-on Board
- The *Nx/DBU Plug-on Board User Manual* (to be inserted into main TSU user manual)
- The Y cable used to break apart the V.35 and DBU connections

Customer Provides

- DTE cable
- DCE cable

ATTACHING THE PLUG-ON BOARD

Placement of the Plug-on Board

Figure 2-1 shows the proper placement of the plug-on board to the option module. Perform the following steps to install the plug-on board:

1. Hold the plug-on board above the option module.
2. Using a downward and right to left motion, slip the V.35 connector plug into the opening in the option module back panel.
3. Moving the plug-on board downward, secure the connection of the header pins at the front of the boards.
4. Install the two 4-40 screws at both edges of the option module.




Figure 2-1. Attaching the Plug-on Board

WARNING

The connection of the header pins between the option module and the plug-on board must be visually verified. Improper connections can severely damage the equipment.

WIRING

The Nx/DBU plug-on board has one V.35 Winchester-style connection. The Nx and DBU connection is defined in Table 2-1, below, and Table 2-2 on page 2-4.

Table 2-1. Nx/DBU Pin Connection

Pin	CCITT	Description
A	101	Protective ground (PG)
B	102	Signal ground (SG)
C	105	Request to send (RTS) from DTE
D	106	Clear to send (CTS) to DTE
E	107	Data set ready (DSR) to DTE
F	109	Received line signal detector (DCD) to DTE
R	104	Received data (RD-A)
T	104	Received data (RD-B)
V	115	RX clock (RC-A) to DTE
X	115	RX clock (RC-B) to DTE
P	103	Transmitted data(TD-A) from DTE
S	103	Transmitted data(TD-B) from DTE
Y	114	TX clock (TC-B) to DTE
AA	114	TX clock (TC-B) to DTE
U	113	External TX Clock (TC-A) from DTE
W	113	External TX clock (ETC-B) from DTE
NN	-	Test mode (TM) to DTE

Table 2-2. DBU V.35 Winchester Pin Connection

Pin	CCITT	Description
A	101	Protective ground (PG)
B	102	Signal ground (SG)
J	105	Request to send (RTS) from DCE
M	106	Clear to send (CTS) from DCE
N	107	Data set ready (DSR) from DCE
BB	109	Received line signal detector (DCD) from DCE
MM	-	Data terminal ready (DTR) to DCE
Z	-	Ring indicator (RI) from DCE
DD	104	Received data (FD-B) from DCE
FF	104	Received data (RD-B) from DCE
HH	115	RX clock (R-B) from DCE
JJ	115	RX clock (RC-B) from DCE
CC	103	Transmitted data (TD-A) to DCE
EE	103	Transmitted data (TD-B)
KK	114	TX Clock (TC-A) from DCE
LL	114	TX clock (TC-B) from DCE

The Nx/DBU Plug-on board cable assembly is shown in Figure 2-2. The schematic for this cable assembly is shown in Figure 2-3 on page 2-6.




Figure 2-2. Nx/DBU Plug-On Board Cable Assembly




Figure 2-3. Nx/DBU Plug-On Board Cable Schematic

POWER-UP TESTING AND INITIALIZATION

The plug-on board executes a self-test during the power-up sequence, as described in the TSU manual. No initialization input is required. Upon power-up, any previously configured setting for the plug-on board is automatically restored.

When self-testing is completed and configuration is successfully restored, the LED labeled **OK** in the MODULE group on the front panel turns **ON**. If any alarms are detected during operation, the red LED labeled **ALARM** in the MODULE group on the front panel turns **ON**.

For more information about the front panel, see the *Operation* chapter of the appropriate TSU user manual.

OVERVIEW

The Nx/DBU plug-on board is controlled as part of the TSU using the same methods as described in the appropriate TSU User Manual.

Front Panel Indicators/Buttons

Refer to the description of the TSU front panel indicators and buttons in the appropriate TSU User Manual.

Menu Structure

The Nx/DBU plug-on board menus appear as a subset of, and operate the same as, menus for the TSUs. The menus are accessed by selecting 1.1 Nx/DBU under the PORT menu items.

The main menu for the TSU 100 is used for illustrative purposes. The main menus for the other TSU units operate in a similar way. Figure 3-1 on page 3-2 shows the TSU 100 main menu with the PORT 1.1 Nx/DBU menu items printed in bold italicized letters.

Complete menu trees for each TSU product is found in their respective user manuals.

TSU 100 MAIN MENU	1) STATUS		1) NI PERF REPORTS
			2) NI ERRORS
	2) CONFIG	1) NETWORK (NI)	3) ACTIVE ALARMS
		2) UNIT	4) VIEW HISTORY
		3) MAP XCHNG	5) PORT STATUS
		4) MAP IN USE A(B)	
		5) DS0 MAP A	
		6) DS0 MAP B	
		7) PORT CONFIG	
	3) UTIL		1) TIME/DATE
			2) FACTORY RESTORE
			3 SET PASSCODE
			4) UNIT ID
			5) PORT UTILITY
			6) SOFTWARE REV
	4) TEST	1) NETWORK TESTS	7) ENET ADDRESS
		2) RUN SELF-TEST	8) SERIAL NUMBER
		3) PORT TEST	
		4) CANCEL TEST	

Figure 3-1. TSU 100 Main Menu Tree

Nx/DBU Menus Are All Submenus

The Nx/DBU plug-on board menus are accessed from and operated the same as menus for the TSU 100. Menu items in the main menu in Figure 3-1 printed in bold italics are submenu choices for the Nx/DBU plug-on board. See Figure 3-2 for the menu tree for each of these submenu options. Each of the these submenu items is discussed in the following paragraphs. All are accessed by the same method.

Operation

With the cursor on one of the four main menu choices, press **Enter** or the **number** key. The results are the first two submenu items with the cursor on the first item. Use the **Scroll Down** key to place the cursor on the desired item then press **Enter**. This displays the first two submenu choices.




Figure 3-2. Nx/DBU Plug-On Board Menu Tree

The Nx/DBU plug-on board menu tree selections are discussed on the following pages.

PORT STATUS, SUBMENU OF STATUS

The Status menu branch provides the ability to view the status of the TSU 100 operation. It displays the status of the monitored signal line on the Nx/DBU plug-on board and the data rate for which the plug-on board is configured.

Operation

To display Figure 3-3 on the TSU 100, place the cursor on **STATUS** and do the following:

1. Press **Enter** or the number **1** key. This displays the first two Status submenu items with the cursor on **NI PERF RPTS**.
2. Use the **Scroll Down** key to place the cursor on **PORT STATUS** and press **Enter**. This displays the first available port.
3. Use the scroll keys to identify **1.1 Nx/DBU** and press **Enter**.




Figure 3-3. Port Status Submenu

The base Nx interface shows the status screens listed in this manual. For other plug-on boards, refer to the appropriate TSU User Manual.

Nx/DBU Status Menu Options

Select **1.1 Nx/DBU**. The following five menu options are available:

DTE DATA/CLOCK

Shows the status (active or not active) of the following lines:

TXD	Transmit data to the DTE
RXD	Receive data from the DTE
ETC	External transmit clock from DTE
LCK	Lock status of the phase locked loop

DTE STATUS

Shows the status (active or not active) of the following lines:

RTS	Request to send from DTE
CTS	Clear to send to DTE
DCD	Data carrier detect to DTE
DSR	Data set ready to DTE

DTE PORT RATE

Displays the data rate to which the Nx port is set.

DBU DATA/CNTRL

Shows the status (active or not active) of the following lines:

TXD	Transmit data to the DCE
RXD	Receive data from the DCE
DCD	Data carrier detect from DCE
RI	Ring indicate from DCE

DBU CONTROL

Shows the status (active or not active) of the following lines:

RTS	Request to send to DCE
CTS	Clear to send from DCE
DTR	Data terminal ready to DCE
DSR	Data set ready from DCE

DBU STATUS

Shows current backup state (see Figure 3-4).




Figure 3-4. DBU Status Submenu

DBU SECS	Total seconds the plug-on board has been in backup.
IN DBU - YES	Module is in backup mode.
- NO	Module is not in backup mode

Exit the displays as described in the appropriate *TSU User Manual*.

PORT CONFIG, SUBMENU OF CONFIG

The **PORT CONFIG** submenu is used for configuration of the Nx/DBU plug-on board.

Operation

To display Figure 3-5 on the TSU 100, place the cursor on **CONFIG** and do the following:

1. Press **Enter** or the number **2** key. This displays the first two Configuration submenu items with the cursor on **NETWORK (NI)**.
2. Use the **Scroll Down** key to place the cursor on **PORT CONFIG** and press **Enter**.
3. Use the scroll keys to identify the **1.1 Nx/DBU** plug-on board. Only the bottom line of the display changes.




Figure 3-5. Port Configuration Submenu

To select **PORT CONFIGURATION**, press **Enter**. This displays the following menu options:

- Nx56/64 CONFIG
- DBU CONFIG

Place the cursor over the desired option and press **Enter** to configure. Menu options for the Nx56/64 and the DBU are shown on the following pages.

Nx56/64 CONFIG Menu Options

Select the **Nx56/64** menu option to access the following eight menu options:

DS0 RATE

This sets the base rate of the interface. The actual data rate depends on the number of DS0s assigned to the DTE Data Rate Chart in the appropriate *TSU User Manual*.
Choices - 56K or 64K

TX CLK CNTRL

Controls the clock used by the TSU 100 to accept the transmit (TX) data from the DTE. Normally this is set to **INTERNAL**. If the interface cable is long, causing a phase shift in the data, the clock can be selected as **INT/INV (INTERNAL/INVERTED)**. This switches the phase of the clock which should compensate for a long cable.
Choices - Normal or Invert

DATA

Used to control the inverting of the DTE data. This inversion can be useful when operating with a high level data link (HDLC) protocol. Often used as a means to ensure 1s density.
Choices - Normal or Invert

Table 3-1 shows the conditions which cause the port control signal to be deactivated.

Table 3-1. Normal Mode Operation

Signal	RTS	V.54 Loopback	511 Test On	Self-Test Active	Network Test Active	NO DS0 Mapped	Network Alarm*
CTS	Follows	Off	Off	Off	Off	Off	Off
DCD	-	-	-	Off	-	Off	Off
DSR	-	Off	Off	Off	Off	Off	-
- Do not care							
* Until backup becomes active							

CTS

Used to control characteristics of CTS.

Choices - Normal or Force On (see Table 3-1 on page 3-8).

DCD

Data Carrier Detect - Indicates to the DTE when a valid signal is being received at the Network Interface.

Choices - Normal or Force On (see Table 3-1 on page 3-8).

DSR

Data Set Ready - This signal indicates to the DTE when the DCE is turned on and ready for operation.

Choices - Normal or Force On (see Table 3-1 on page 3-8).

0 INHIB

If the Nx interface detects an uninterrupted string of -0s being transmitted toward the network, and if 0s are transmitted for more than one second, then the TSU 100 forces 1s towards the network.

Choices - On or Off

INBAND MODE

Inband Configuration Channel - Used to enable/disable an 8 kbps remote configuration channel (see Figure 3-6 on page 3-10).

When this option is set to On, the first DS0 mapped to the Nx interface operates in 56K mode and the DTE clock rate is reduced by 8 kbps. The TSU uses this 8 kbps channel to send and receive configuration data across a T1 span. As shown in Figure 3-6, this allows the PC connected to the chain-in port on TSU 600 A to monitor/configure both TSU 600 A and B. This feature is useful when FDL connectivity is not available across the T1 span.

This 8 kbps channel is only taken out of the first DS0. If two 64K DS0s are mapped, the DTE rate would be 120 kbps instead of 128 kbps.




Figure 3-6. Inband Remote Configuration

If the inband configuration channel is enabled, the Nx/DBU will use the channel to verify end-to-end connectivity of the T1 network. This provides more robust monitoring of the primary network. This is especially useful in networks where alarms are not passed end-to-end.

DBU CONFIG Menu Options

Select the **DBU CONFIG** menu option to access the 11 menu options discussed in this section.

BACKUP MODE

The DBU can activate backup in two basic modes: **SINGLE END FAILURE** or **BOTH END FAILURE**. These can be used to control how calls are established and which end initiates the dialing process.

Choices: **DISABLE**, **ORIGINATE**, **ANSWER**, **ORIG/ANS ANY**

SINGLE END FAILURE

In this mode, a backup condition detected at either end of the circuit causes a backup to be activated. The DBU at the failed end initiates a call to the opposite end which goes into backup mode upon receiving a call. This is particularly useful for Fractional T1 applications where a failure at one end cannot be reported to the other end.

Choices: Mode: ORIG/ANS ANY



In this mode, if the unit has Pattern Verify turned Off, it will go into backup mode on any received call, even a wrong number.

BOTH END FAILURE

In this mode, both ends of the circuit must detect backup conditions before backup is activated. One DBU is set to **ORIGINATE** and the other to **ANSWER**. Upon a network failure, only the Originate DBU initiates backup by dialing the Answer end. Once called, the Answer DBU goes into backup mode only if a backup condition is detected. This is ideal for controlling where calls originate.

Choices: Mode: ORIGINATE or ANSWER

BACKUP ON

This selects the conditions that cause the Nx/DBU to initiate Backup.

Choices: NET FAIL, NET/DATA FAIL

NET FAIL

Backup occurs on RED ALARM, YELLOW ALARM, BLUE ALARM, AND LOS.

NET/DATA FAIL

Backup occurs on the same conditions as NET FAIL plus loss of data transitions on the data the Nx56/64 receives from the network.

PATTERN VERIFY

This selects whether or not the DBU will use its pattern generator and receiver to authenticate backup attempts. When the local and remote units are both Nx/DBUs, set this to Enable; otherwise set this to disable.

Choices: ENABLE, DISABLE

BACKUP DELAY

This selects the time allowed to elapse between the network going into alarm or no data transmissions and the backup beginning.

Choices: 1 sec, 3 sec, 10 sec, 30 sec, 1 min, 5 min, 10 min

RESTORE DELAY

This selects the time that elapses between the network going out of alarm or data and the backup call being taken down. If never is selected, the user must deactivate the backup mode.

Choices: 1 sec, 3 sec, 10 sec, 30 sec, 1 min, 5 min, 10 min, never

RETRY DELAY

This selects the time between redialing the external DCE after failed dial attempts.

Choices: 10 sec, 30 sec, 1 min, 5 min, 10 min

NUM RETRIES

This selects the number of times the DBU will attempt to redial if unable to connect.

Choices: none, unlimited, 3 times, 10 times

BACKUP TESTING

This submenu sets the options for the automatic ISDN **BACKUP TESTING**:

This submenu sets the options for the automatic ISDN verification feature of the Nx/DBU. Verification of the backup circuit does not disrupt data on the T1.

BACKUP TEST

This selects the frequency of automatic backup circuit verification by the DBU.

Choices: MANUAL, HOURLY, DAILY, WEEKLY

TEST HOUR

This selects the hour of the day the backup test will occur.

Choices: 0 to 23

TEST DAY

If weekly backup test is selected, this option will select which day to perform the test.

Choices: MONDAY through SUNDAY

WKEND LOCKOUT

If no backup is desired from midnight Friday to midnight Sunday, set this selection to **ON**, otherwise set to **OFF**.

Choices: ON, OFF

A) ENABLE HR: (0-23)

The hour that the backup will be enabled can be entered from the numeric keyboard.

B) DISABLE HR: (0-23)

The hour that the backup will be disabled can be entered from the numeric keypad.



For items A and B to function properly, verify that the time and date in the TSU are set correctly. Consult the appropriate TSU User Manual for instructions on setting date and time.

C) Trap in DBU

If traps are enabled (see unit configurations), this parameter will send either a single trap upon going into a DBU session or send repeated traps for the duration of the DBU session.

Choices: Single, Repeated

FACTORY RESTORE, SUBMENU OF UTIL

This selection is used to restore the factory default settings for all pass-through plug-on board parameters.

Operation

To return the unit to the opening main menu with all the factory default settings restored, do the following:

1. Follow the standard operating procedure to access the **UTIL** menu items.
2. With the cursor on **FACT RESTORE**, press **Enter**.

PORT UTILITY, SUBMENU OF UTIL

The **PORT UTILITY** submenu is used to access the display of the current software information for each port installed in the unit. This information is required when requesting assistance from ADTRAN Technical Support or when updates are needed.

Operation

To display Figure 3-7 on the TSU 100, do the following:

1. Follow the standard operating procedure to access the **UTIL** menu items.
2. With the cursor on **PORT UTILITY**, press **Enter**. This displays the first available port.




Figure 3-7. Port Utility Submenu

To display the port name and the software version installed as shown in Figure 3-8, do the following:

1. Use the scroll keys to move through the available ports, or enter the port number with the number key.
2. When the desired port name is displayed, press **Enter**.
3. Press **Cancel** to exit or to select another port.




Figure 3-8. Port Name and Software Version Display

RUN SELF-TEST, SUBMENU OF TEST

This menu item is used to execute both the internal test of the TSU and of the Nx/DBU. The results of the self-test are shown on the TSU display. For additional information on self-test, see the Operation chapter of the appropriate TSU user manual.

To activate a self-test, do the following:

1. Follow the standard operating procedure to access the **TEST** menu items.
2. With the cursor on **RUN SELF TEST**, press **Enter**. The TSU display shows the test outcome.

PORT TEST, SUBMENU OF TEST

This menu item is used to activate testing of specific data ports. It also controls the activation of loopbacks and the initiation of data test patterns. Test results are shown on the TSU display.



CAUTION

Port Test execution disrupts normal data flow in the port being tested.

Operation

To display Figure 3-9 on the TSU 100, starting with the cursor on **PORT TEST**, press **Enter** or the number **3** key. This displays the available ports.




Figure 3-9. Port Test Submenu

1.1 Nx/DBU Menu Options

The **1.1 Nx/DBU** interface offers the following seven test functions:

PRT/LOCAL

The Nx port activates both a local loopback (back toward the DTE) and a port loopback when either is invoked. Choices: REMOTE, REM V.54 CONT, OFF

REMOTE

The remote loopback causes a channelized V.54 code to be sent to the far end. The Nx at the far end activates a **PORT/LCL** loopback on detection of the V.54 code.

REM V.54 CONT

This loopback causes a continuous V.54 code to be sent to the far end. The Nx at the far end activates a **PORT/LCL** loopback on detection of the V.54 code.

OFF

The loop is deactivated.



*The TSU checks the remote loopback activation by detecting a proper response from the remote end. While waiting for the response, the display shows **Looping**. If successful, the display changes to **Looped Up**. If unsuccessful, it displays **Failed**.*

511 PATT

Activates the generation of the 511 test pattern toward the T1 network.

Choices: OFF, ON

ON

The pattern check circuitry is enabled and a test started. The test is ended by selecting **OFF**.

OFF

The pattern generation and check is disabled.

511 RESULTS

Displays the results of the 511 test indicated in menu selection 511 PATT.

The results are in the form of the number of errored seconds. The error count can be cleared by pressing the **Clear** key (**Shift + 9**). A bit error may be inserted into the data stream by pressing the **2** key.

DBU LOOPBACK

Activates the generation of the 511 test pattern toward the T1 network.

Choices: OFF, ON

DBU TEST

This selection is used to force a backup to occur even if a backup condition does not exist.

Choices: TESTS OFF, FORCED BACKUP, INTERFACE TST

TESTS OFF

Turns off DBU tests.

FORCED BACKUP

Used to force a backup regardless of time-of-day lock-outs or network conditions.

INTERFACE TST

This test causes the external DCE to dial its stored number. After the connection is established the DBU will send a test pattern to verify the backup network. This test does not disrupt data or the primary network.

DBU DATA/CNTRL

Allows status of DCD and RI to be monitored while the INTERFACE TST is on. If the dial up network is correctly configured and dialed up, there should be an asterisk (*) over DCD.

DBU TST RESULT

When an interface test is active, the screen shown in Figure 3-10 will show the total number of DATA blocks received and the number of blocks with errors.




Figure 3-10. DBU TST Result Submenu

ALARM MESSAGES

Network Interfaces

Red Alarm

NI unable to align frame with incoming signal

Yellow Alarm

Remote alarm indication (RAI) being received from the far end

Blue Alarm

Unframed all 1s (AIS) being received at NI

Loss of Signal

No signal detected at NI

Nx/DBU Plug-on Board

Clock Slip

Difference in frequency of the data clock at the network and DTE

PLL Alarm

Unable to lock phase lock on the clock provided by the network interface

Zeros Alarm

All 0s data being sent to the network interface

No EXT Clock

No external transmit clock at DTE (when applicable)

STATUS MESSAGES

Network Interfaces

Payload On

Payload loopback activated

Line On

Line loopback activated

Loopback Off

All loopbacks deactivated

Factory Restore

Factory setting restored

Power On

Unit powered on

Self-Test

Internal self-test performed

Nx/DBU Plug-on Board

Loop-Up

Data is looped back at both the network interface and the DTE interface of the card

Remote Loop Up

Sending a V.54 pattern in an attempt to loop up a remote device

511 Pattern On

Sending a 511 pattern towards the network interface

Loop Down

Data is no longer looped back at the network interface or the DTE interface

511 Pattern Off

No longer sending a 511 pattern towards the network interface

Index

Numerics

- 0 INHIB 3-9
- 1.1 Nx/DBU Menu Options 3-16
- 1s Density Protection 1-4
- 511 PATT 3-17
- 511 Pattern Off A-3
- 511 Pattern On A-3
- 511 RESULTS 3-18

A

- attaching the plug-on board, how to 2-2

B

- BACKUP DELAY 3-12
- BACKUP MOD 3-10
- backup on 3-11
- BACKUP TEST 3-13
- BACKUP TESTING 3-12
- Blue Alarm A-1
- both end failure 3-11

C

- cables, provided by customer 2-1
- Clock Options 1-4
- Clock Slip A-1
- Connector 1-4
- CTS 3-9
- Customer Service iv

D

- DATA 3-8
- Data Inversion 1-4
- DBU CONFIG Menu Options 3-10
- DBU CONTROL 3-6
- DBU DATA/CNTRL 3-5, 3-18
- DBU Features 1-2

- DBU LOOPBACK 3-18
- DBU STATUS 3-6
- DBU TEST 3-18
- DBU TST RESULT 3-19
- DBU V.35 pinout 2-4
- DCD 3-9
- DCE Interface 1-4
- DISABLE HR
 - (0-23) 3-13
- DS0 RATE 3-8
- DSR 3-9
- DTE DATA/CLOCK 3-5
- DTE PORT RATE 3-5
- DTE STATUS 3-5

E

- ENABLE HR
 - (0-23) 3-13
- Environmental, specifications 1-5

F

- factory restore, operation 3-14
- FACTORY RESTORE, Submenu of UTIL 3-14
- FCC Radio Frequency Interference Statement iv
- Features, DBU 1-2
- Features, Nx 1-2
- Features, of both Nx & DBU 1-3
- Features, of Nx/DBU plug-on board 1-2

I

- INBAND MODE 3-9
- indicator buttons, front panel 3-1
- installation, overview 3-1
- Interfaces & connectors 1-3
- items included in shipments 2-1

L

Loop Down A-3
Loop-Up A-3
Loss of Signal A-1

M

Mechanical, specifications 1-5

N

NET FAIL 3-11
NET/DATA FAIL 3-11
No EXT Clock A-2
NUM RETRIES 3-12
Nx Features 1-2
Nx/ DBU, DTE interface 1-5
Nx/DBU Menus, about 3-2
Nx/DBU pinouts 2-3
Nx/DBU Plug-on Board A-3
Nx/DBU Plug-on board cable assembly 2-5
Nx/DBU plug-on board cable schematic 2-6
Nx/DBU Plug-On Board Menu Tree 3-3
Nx/DBU plug-on board menus 3-1
Nx/DBU Status Menu 3-5
Nx/DBU V.35 plug-on board 1-1
Nx/DBU, specifications 1-4
Nx56/64 and DBU, common specifications 1-5
Nx56/64 CONFIG Menu Options 3-8
Nx56/64, DCE interface 1-4

P

PATTERN VERIFY 3-12
Physical Description 1-6
pinout, for DBU V.35 2-4
pinouts, for Nx/DBU 2-3
PLL Alarm A-1
PORT CONFIG 3-7
port config, operation 3-7
PORT Status 3-4
port status, operation 3-4
port test, operation 3-16
port test, Submenu of test 3-16
port utility, operation 3-14

port utility, submenu of UTIL 3-14
Power-Up Testing and Initialization 2-7
product warranty v
PRT/LOCAL 3-16

R

Rates 1-4
Red Alarm A-1
Remote Loop Up A-3
RESTORE DELAY 3-12
RETRY DELAY 3-12
run self-test, submenu of test 3-15

S

self-test A-2
self-test, to activate 3-15
single end failure 3-11
specification, of Nx/DBU 1-4
Status Message A-2

T

TEST DAY 3-13
TEST HOUR 3-13
Test Pattern 1-4
Tests 1-4
Tests, specifications 1-5
TSU 100 main menu tree 3-2
TX CLK CNTRL 3-8

U

Unpack & Inspect 2-1

W

Warranty and Customer Service iv
Wiring 2-3
WKEND LOCKOUT 3-13

Y

Yellow Alarm A-1

Z

Zeros Alarm A-2

Product Support Information

Pre-Sales Inquiries and Applications Support

Please contact your local distributor, ADTRAN Applications Engineering, or ADTRAN Sales:

Applications Engineering (800) 615-1176

Sales (800) 827-0807

Post-Sale Support

Please contact your local distributor first. If your local distributor cannot help, please contact ADTRAN Technical Support and have the unit serial number available.

Technical Support (888) 4ADTRAN

Repair and Return

If ADTRAN Technical Support determines that a repair is needed, Technical Support will coordinate with the Customer and Product Service (CaPS) department to issue an RMA number. For information regarding equipment currently in house or possible fees associated with repair, contact CaPS directly at the following number:

CaPS Department (256) 963-8722

Identify the RMA number clearly on the package (below address), and return to the following address:

ADTRAN, Inc.
CaPS Department
6767 Old Madison Pike
Progress Center
Building #6, Suite 690
Huntsville, AL 35807

RMA # _____

