



Q&A

Not all of my PVCs are displayed in the DLCI list of my FRAD product. What do I do?

Q: Not all of my PVCs are displayed in the DLCI list of my FRAD product. What do I do?

A: If known PVCs from your service provider do not show up in the DLCI list, try increasing the maximum PVC count. If they do not show up after you have increased the max PVC count, contact your service provider.

*Note: The DLCI List can be accessed via a terminal session with unit. Use the + key to page down the DLCI list to the next page of the list. If you are using the front panel on the unit (except the NxIQ product), push the * (Shift) then 7 (Next) keys to display the next entry in the list.*
