



Q&A

What is the correct setting for the Line Length option on the DS3 interface of a T3SU 300?

Q:

What is the correct setting for the Line Length option on the DS3 interface of a T3SU 300?

A:

The line length is set to reflect the physical length of the DS3 network line as measured from the demarc to the unit.

There are two settings for line length: long and short. This setting should be set according to the cabling distance shown in parenthesis, which varies depending on the version of the unit.

First generation T3SU 300s use Long for distances over 50 feet and Short for distances under 50 feet. Second generation T3SU 300s use Long for distances over 225 feet and Short for distances under 225 feet.
