

New Dial Plan & mapping. Only using Network Slot1 for T1.

```

ATLAS 550 B/Dial Plan/User Term
Network Term # Slot/Svc Port/PEP Sig In#Accept Out#Rej Ifce Config
User Term 1 N1>T1/PRI-1 1>T1/PRI PRI [$] [+] [+]
Global Param 2 N1>T1/PRI-1 1>T1/PRI PRI [0051] [+] [+]
3 N1>T1/PRI-1 1>T1/PRI PRI [0055] [+] [+]
4 N1>T1/PRI-1 1>T1/PRI PRI [1054] [+] [+]
5 N1>T1/PRI-1 1>T1/PRI PRI [8186] [+] [+]
6 N1>T1/PRI-1 1>T1/PRI PRI [0060] [+] [+]
7 N1>T1/PRI-1 1>T1/PRI PRI [0059] [+] [+]
8 N1>T1/PRI-1 1>T1/PRI PRI [0057] [+] [+]
9 N1>T1/PRI-1 1>T1/PRI PRI [0058] [+] [+]
  
```

User Term1 Interface Config

```

ATLAS 550 B/Dial Plan/User Term[1]/Interface Configuration
Incoming Number Accept List Switch Type National ISDN
Outgoing Number Reject List First DS0 1
Interface Configuration Number of DS0s 15
Substitution Template Strip MSD None
Ntwrk Spec. Fac. - Uoice Normal
Ntwrk Spec. Fac. - Data Normal
Called Digits Transferred All
Outgoing Caller ID Send as provided
Source ID 0
Swap ANI/DNIS Disabled
B Channel Selection Circular
Busy Option Normal
B Channel Restarts Enabled
  
```

SYS: OK NETWK1:ALRM NETWK2: -- 1:ONLN 2: OK 3: OK 4: OK
 ^Z=help 18:59

User Term2 Interface Config (User Term3-9 Identical with different incoming number)

```

ATLAS 550 B/Dial Plan/User Term[2]/Interface Configuration
Incoming Number Accept List  Switch Type          National ISDN
Outgoing Number Reject List First DS0             16
Interface Configuration     Number of DS0s       1
Substitution Template       Strip MSD             None
                             Ntwrk Spec. Fac. - Uoice Normal
                             Ntwrk Spec. Fac. - Data Normal
                             Called Digits Transferred All
                             Outgoing Caller ID   Send as provided
                             Source ID             0
                             Swap ANI/DNIS         Disabled
                             B Channel Selection   Normal
                             Busy Option           Normal
                             B Channel Restarts     Enabled
    
```

SYS: OK NETWK1:ALRM NETWK2: -- 1:ONLN 2: OK 3: OK 4: OK

^Z=help 19:00

Dedicated Map

```

ATLAS 550 B/Dedicated Maps/Create/Edit Maps[1]/Connects
Connects # FROM SlT Port TO SlT/S Prt/PEP From Config To Config SIG
Enbl Day 1 S4>FXS-8 1>FXS 4 N1>T1/PR 1>T1/PR [Port=1] [DS0=16]
2 S4>FXS-8 2>FXS 4 N1>T1/PR 1>T1/PR [Port=2] [DS0=17]
3 S4>FXS-8 3>FXS 4 N1>T1/PR 1>T1/PR [Port=3] [DS0=18]
4 S4>FXS-8 4>FXS 4 N1>T1/PR 1>T1/PR [Port=4] [DS0=19]
5 S4>FXS-8 5>FXS 4 N1>T1/PR 1>T1/PR [Port=5] [DS0=20]
6 S4>FXS-8 6>FXS 4 N1>T1/PR 1>T1/PR [Port=6] [DS0=21]
7 S4>FXS-8 7>FXS 4 N1>T1/PR 1>T1/PR [Port=7] [DS0=22]
8 S4>FXS-8 8>FXS 4 N1>T1/PR 1>T1/PR [Port=8] [DS0=23]
    
```